



31 DVI Stone Set Installation Instructions (sku 94700729)

Packing List

- Steel Template
- Pilot Cover Rock (has cut-out on bottom of rock)
- Pilot Shield Rock (has two holes on bottom of rock)
- (12) Standard Rocks (has one hole on bottom of rock)
- Platinum Crushed Glass (1 lb. or 1-1/2 cups)
- Bronze Crushed Glass (1 lb. or 1-1/2 cups)
- Cobalt Crushed Glass (1 lb. or 1-1/2 cups)

Installation Warnings

- **The rocks are fragile, especially after being exposed to heat.**
- Make sure the gas control valve is "OFF" and the heater is cool prior to conducting service.
- Failure to position the parts in accordance with these diagrams or failure to use only parts specifically approved with this appliance may result in property damage or personal injury.
- The burner must be correctly positioned before installing the rocks. Make sure the burner is fully seated and the pilot is properly aligned. See owner's manual for details on burner removal.

HINT: If using propane (LP), convert the appliance before installing the rocks.

Steel Template Installation

The template is shipped with the small tabs bent up. Bend the three large tabs up 90° (see pictures below).



Place the template over the burner as shown below. Note how the template fits over the pins on the burner.





31 DVI Stone Set Installation Instructions (sku 94700729)

Pilot Cover Rock and Pilot Shield Rock Installation

There are two unique rocks included with this rock set. One rock covers the pilot, the other shields it. Follow the directions below to install these rocks.

Pilot Cover Rock

Pilot Shield Rock



The pilot cover rock has two holes on one side that fit over the tabs to the left of the pilot. Place the rock as shown below.



The pilot shield rock has two holes that fit over the tabs on the right side of the pilot as shown below.

WARNING: Make sure the small hole inserts over the pin on the right side (incorrect placement may lead to sooting and burner malfunction).





31 DVI Stone Set Installation Instructions (sku 94700729)

Rock Installation

The remaining rocks may now be placed on the burner so the hole on each rock inserts over the pins on the burner. Start with the rocks to the left of the pilot, working your way clockwise around the burner (see photos below).



HINT: When placing the rocks, you may rotate them to achieve an aesthetic look. Pay close attention to rock shading to make sure the rocks appear random.

WARNING: Make sure the rocks are not directly over any burner holes.

HINT: For those rocks that are elevated, you may bend the pin on the template to allow for correct placement.





31 DVI Stone Set Installation Instructions (sku 94700729)

Crushed Glass Installation

Three colors of crushed glass are included with this set to allow for different shading options.



Pour one bag of crushed glass onto the burner in a thin, uniform layer.



WARNING: Make sure the glass is only one layer thick. If the glass is too thick it will impair burner performance and create soot.

