

Victorian Lace DVL Face

Black 95200532

Compatibility

DVL Insert

Packing List

- Face
- (4) 10-24 Nuts
- Left and Right Bracket

• (4) 1/4-20 Screws

• (2) Cove Covers

Installation



WARNING:

Make sure the heater has fully cooled prior to conducting service.

- Install the surround panels.
- 2 Install the face following the directions to the right

face.

